

Fisher® Posi-Seal™ A31A High Performance Butterfly Valve 3 through 12-Inch

Contents

Introduction	1
Scope of Manual	1
Specifications	2
Description	1
Installation	2
Adjusting the Actuator Travel Stops or Travel ..	3
Valve Orientation	3
Preparing for Installation	7
Installing Wafer-Style Valves	8
Installing Single-Flange Valves	9
Maintenance	9
Replacing Packing	10
Removing the Valve from the Pipeline	11
Removing/Installing the Seal Ring	12
PTFE Seal Installation	12
NOVEX Seal and Phoenix III	12
Fire-Tested Seal Installation	12
Cryogenic Seal Installation	14
Anti-Blowout Protection, Packing, Valve Shaft(s), Disk, and Bearing Maintenance	15
Removal	15
Installing a One-Piece Shaft	17
Installing a Two-Piece Shaft	18
Installing the Gasket Retainer	19
Parts Ordering	19
Parts Reference	19

Introduction

Scope of Manual

This instruction manual provides installation, maintenance, and parts ordering information for the




Figure 1. Typical Type A31A Valve

POSI-SEAL Type A31A high-performance butterfly valves. Figure 1 shows typical Type A31A valves. For information regarding actuators and accessories, refer to separate instruction manuals.

Only personnel qualified through training or experience should install, operate, and maintain this valve. If you have any questions concerning these instructions, contact your Fisher Controls sales representative or sales office before proceeding.

Description

The Type A31A high-performance butterfly valve features a keyed drive shaft. The keyed shaft combines with a variety of hand levers, handwheels, pneumatic piston or spring-and-diaphragm actuators to make the Type A31A a reliable, high-performance, butterfly valve for a variety of applications in the various process industries.



A31A Valve

Table 1. Specifications

<p>Available Valve Configurations</p> <ul style="list-style-type: none"> ■ Flangeless, wafer-style or ■ single-flange (lugged) control valve with a one-piece valve body and a two-component seal/backup O-ring, and a keyed drive shaft <p>Valve Sizes</p> <ul style="list-style-type: none"> ■ 3, ■ 4, ■ 6, ■ 8, ■ 10, ■ 12-inch <p>End Connection Style</p> <ul style="list-style-type: none"> ■ Flangeless, wafer-style or ■ single flange valve body designed to fit between raised-face mating flanges per ASME B16.5 Class 150 or 300 <p>Maximum Inlet Pressure/Temperature⁽⁴⁾</p> <p>Consistent with ANSI Class ■ 150 and ■ 300 pressure/temperature ratings per ASME B16.34. Also, see figure 2 for additional information.</p> <p>Available Seal Configurations</p> <ul style="list-style-type: none"> ■ Standard soft seal ring (PTFE) with fluoroelastomer or EPR backup ring, ■ NOVEX seal ring, Class 150, (S31600, 316 SST)⁽¹⁾ ■ NOVEX seal ring, Class 300, standard pressure rating (S31600, 316 SST)⁽¹⁾ ■ NOVEX seal ring, Class 300, high pressure rating (S21800, Nitronic 60), ■ Phoenix III fire-tested seal ring (S31600, 316 SST) with resilient insert (PTFE) and backup ring (fluoroelastomer), or ■ cryogenic seal ring (Kel-F) with optional backup ring (aluminum) 	<p>Valve Classification</p> <p>Face-to-face dimensions are in compliance with MSS SP68 and API 609 standards; valve bodies are designed for installation between ASME B16.5 Class 150 or 300 raised-face flanges</p> <p>Shutoff Classification. Per ANSI/FCI 70-2</p> <p>Standard Soft Seal: Bidirectional bubble-tight shutoff</p> <p>NOVEX Seal: Unidirectional shutoff Class V (reverse flow direction only)</p> <p>Phoenix III Seal: Bidirectional bubble-tight shutoff</p> <p>Phoenix III Seal for Fire-Tested Applications: Consult your Fisher Controls sales office or representative for fire tested performance</p> <p>Cryogenic seal applications: Consult your Fisher Controls sales office or sales representative</p> <p>Installed Valve Orientation</p> <p>See figure 3 for orientation guidelines for optimum seal performance</p> <p>Valve In-Line Position</p> <p>Shaft horizontal. See figure 5</p> <p>Available Actuators</p> <ul style="list-style-type: none"> ■ Handlever, ■ handwheel, ■ spring-and-diaphragm, or ■ pneumatic piston <p>Disk Rotation</p> <p>Clockwise to close</p>
---	--

1. For specific information about materials of construction, contact your nearest Fisher Controls sales office or representative.
 2. The pressure/temperature limits in this manual, and any applicable code or standard limitation, should not be exceeded.

The Type A31A is available in either a flangeless (wafer) or a single-flange (lugged) valve design, with a variety of seal, valve body, and internal components. The Type A31A valve features a dynamic sealing design that is used in a variety of demanding applications. With the appropriate seal configuration and materials of construction, the pressure-assisted seal provides shutoff against the full ANSI class pressure range for the specific valve type.

Installation



To avoid personal injury or property damage resulting from the sudden release of pressure, do not install the valve assembly where service conditions could exceed the limits

given in this manual or on appropriate nameplates. Use pressure-relieving devices as required by government or accepted industry codes and good engineering practices.

the valve without first contacting your Fisher Controls sales office or sales representative.

The maximum allowable inlet pressures for Type A31A valves are consistent with the applicable pressure/temperature ratings except where limited by material capabilities shown in figure 2 and table 2.

Table 2. Material Temperature Ratings

COMPONENT, ANSI CLASS, MATERIAL OF CONSTRUCTION	TEMPERATURE RANGE	
	°F	°C
Seal Ring	See Figure 2	
Backup Ring		
Soft Seal		
Fluoroelastomer	-20 to 400	-29 to 204
EPR	-65 to 360	-54 to 182
Nitrile	-20 to 200	-29 to 93
PTFE	-100 to 400	-73 to 204
Neoprene	-45 to 300	-43 to 149
Phoenix III Seal		
Fluoroelastomer	-40 to 500	-40 to 260
EPR	-80 to 400	-62 to 204
Nitrile	-40 to 300	-40 to 149
Neoprene	-65 to 300	-59 to 149
Cryogenic Seal		
Aluminum (Optional)	-425 to 400	-254 to 204
Shaft Packing⁽¹⁾		
PTFE	-425 to 450	-254 to 232
Graphite		
In Oxidizing Media	-425 to 1000	-254 to 538
In Inert or Reducing Media	-425 to 1500	-254 to 816
Shaft⁽²⁾		
17-4PH H1025	-100 to 800	-73 to 427
17-4PH H1150M	-320 to 800	-195 to 427
K-Monel	-425 to 900	-254 to 482
Inconel 718	-425 to 1300	-254 to 704
Nitronic 50	-320 to 1100	-196 to 593
Bearings		
PEEK ⁽³⁾ (standard)	-100 to 500	-73 to 260
316 SST	-425 to 1500	-254 to 816
PTFE Composition	-425 to 325	-254 to 163
Bronze	-425 to 500	-196 to 260
Disk Hardfacing		
Electroless Nickel Plating or hard chrome coating	-425 to 1000	-254 to 538
CoCr-A ⁽⁴⁾ (Alloy 6)	-325 to 1500	-198 to 816
1. These low temperature limits apply to the flowing media. Valve extensions provided for cryogenic service maintain higher temperatures at the packing box. 2. Shaft material may affect the valve pressure rating. Consult your Fisher Controls sales office or sales representative. 3. PEEK stands for PolyEtherEtherKetone 4. CoCr-A hardfacing degrades shutoff performance of the seal. Consult your Fisher Controls sales office or sales representative.		

Adjusting the Actuator Travel Stops



WARNING

The edges of a rotating valve disk have a shearing effect that may result in personal injury. To avoid personal injury, keep clear of the disk edges when rotating the disk.



CAUTION

When using an actuator, the actuator travel stops or the actuator travel (for actuators without adjustable stops) must be adjusted so that the disk stop in the valve body does not absorb the output of the actuator. Failure to limit actuator travel as described in the next step can result in damage to the valve shafts or other valve parts.

1. Locate the actuator travel stop that establishes the closed position of the valve disk. When adjusting the travel stop or travel, make sure that the disk is from 0.001 to 0.030 inch (0.03 to 0.76 mm) away from the internal stop in the valve body. This adjustment is necessary to be certain that the actuator output torque is fully absorbed by the actuator travel stop or by the actuator. The internal travel stop in the valve body should not absorb any of the actuator torque.
2. Before installing the valve/actuator assembly in the process line, cycle the valve several times to be sure the valve disk returns to the proper position.

Valve Orientation

Note

The 10- through 12-inch class 150 valves and 8- through 12-inch class 300 valves have a two-piece shaft. The



CAUTION

The valve configuration and construction materials are selected to meet particular pressure, temperature, pressure drop, and controlled fluid conditions. Because pressure drop and temperature range capabilities limit some combinations of materials, do not apply any other conditions to

A31A Valve

shaft with the keyed end is called the drive shaft. The shaft opposite the drive shaft is called the follower shaft.

The 3- through 8-inch class 150 valves and 3- through 6-inch class 300 valves have a one-piece shaft. This one-piece shaft is keyed and is called the drive shaft.

Whenever possible, install the valve with the shaft in the horizontal position as shown in figure 5.

Horizontal installation can enhance valve performance because process

The Type A31A valve is designed for installation with the shaft(s) in any orientation around the pipeline: horizontal, vertical, or at an intermediate angle. However, when installing the valve in certain services, follow the recommendations below, which are based on application experience:

- In certain services (process fluids with high concentrations of entrained solids, abrasive slurries, polymerizing media, or large diameter valves with high flow rates), installing the valve with the shaft horizontal to the pipeline and downstream of the seal will enhance valve performance.

- Install a valve supplied for uni-directional shutoff with the high pressure side in the direction noted on the valve body. A flow tag with an arrow is provided for proper installation.

If you have questions about proper valve orientation in a specific application, contact your Fisher Controls representative or sales office.

Table 3. Valve Body Data, Class 150

VALVE SIZE, INCHES	SHAFT DIA. AT YOKE BEARING	FACE-TO-FACE DIMENSION ⁽¹⁾	MINIMUM I.D. ⁽²⁾	APPROX. WEIGHT, POUNDS	
				Wafer	Single-Flange
	Inches				
3	9/16	1-7/8	2.82	19	21
4	11/16	2-1/8	3.69	28	32
6	15/16	2-1/4	5.80	45	49
8	15/16	2-1/2	7.70	61	67
10	1-1/8	2-13/16	10.00	73	95
12	1-1/4	3-3/16	11.76	105	141
VALVE SIZE, INCHES	SHAFT DIA. AT YOKE BEARING	FACE-TO-FACE DIMENSION ⁽¹⁾	MINIMUM I.D. ⁽²⁾	APPROX. WEIGHT, KILOGRAMS	
				Wafer	Single-Flange
	mm				
3	14.3	47.6	71.6	8.6	9.5
4	17.5	54.0	93.7	13	15
6	23.8	57.2	147.3	20	22
8	23.8	63.5	195.6	28	30
10	28.5	71.4	254.0	33	43
12	31.8	81.0	298.7	48	64


1. Face-to-face dimensions are in compliance with MSS SP68 and API 609 specifications.
2. Minimum I.D. is the minimum pipe or flange I.D. required for disk swing clearance.

fluid flow will sweep entrained solids from valve surfaces, preventing particle buildup on the seal. Also, installation of the valve with the shaft horizontal will extend bearing life because entrained solids will be less likely to penetrate the bearings.

Table 4. Valve Body Data, Class 300

VALVE SIZE, INCHES	SHAFT DIA. AT YOKE BEARING	FACE-TO-FACE DIMENSION ⁽¹⁾	MINIMUM I.D. ⁽²⁾	APPROX. WEIGHT, POUNDS	
				Wafer	Single-Flange
	Inches				
3	9/16	1-7/8	2.82	20	23
4	11/16	2-1/8	3.69	28	31
6	15/16	2-5/16	5.80	44	54
8	1-1/4	2-7/8	7.33	67	91
10	1-5/8	3-5/16	9.10	134	166
12	1-7/8	3-5/8	11.09	171	235
VALVE SIZE, INCHES	SHAFT DIA. AT YOKE BEARING	FACE-TO-FACE DIMENSION ⁽¹⁾	MINIMUM I.D. ⁽²⁾	APPROX. WEIGHT, KILOGRAMS	
				Wafer	Single-Flange
	mm				
3	14.3	47.6	71.6	9.1	10
4	17.5	54.0	93.7	13	14
6	23.8	58.7	147.3	20	25
8	31.8	73.0	186.2	30	41
10	41.3	84.1	231.1	61	75
12	47.6	92.1	281.7	78	107

1. Face-to-face dimensions are in compliance with MSS SP68 and API 609 specifications.
2. Minimum I.D. is the minimum pipe or flange I.D. required for disk swing clearance.



NOTE:


① BECAUSE OF POTENTIAL EROSIVE EFFECTS AND PREMATURE SEAL FAILURE THAT CAN OCCUR, THROTTLING PTFE SEALS AT DIFFERENTIAL PRESSURES GREATER THAN 300 PSID AT DISC ANGLES LESS THAN 20° OPEN IS NOT RECOMMENDED.

② TEMPERATURE LIMITATIONS DO NOT ACCOUNT FOR THE ADDITIONAL LIMITATIONS IMPOSED BY THE BACKUP RING USED WITH THIS SEAL. TO DETERMINE THE EFFECTIVE TEMPERATURE LIMITATION OF THE APPROPRIATE SEAL/BACKUP RING COMBINATION, REFER TO TABLE 3.


B2335-2/1L

Figure 2. Maximum Pressure/Temperature Ratings


A31A Valve




CLASS 150, PHOENIX III SEAL



CLASS 300, PHOENIX III SEAL



CLASS 150, CRYOGENIC SEAL




CLASS 300, CRYOGENIC SEAL

NOTE:
 ② TEMPERATURE LIMITATIONS DO NOT ACCOUNT FOR THE ADDITIONAL LIMITATIONS IMPOSED BY THE BACKUP RING USED WITH THIS SEAL. TO DETERMINE THE EFFECTIVE TEMPERATURE LIMITATION OF THE APPROPRIATE SEAL/BACKUP RING COMBINATION, REFER TO TABLE 3.

B2336-1/L

Figure 2. Maximum Pressure/Temperature Ratinas (continued)



NOTE:
 1 FOR OPTIMUM SEAL PERFORMANCE, THE PREFERRED VALVE ORIENTATION AT SHUTOFF IS WITH THE RETAINING RING DOWNSTREAM FROM THE HIGH PRESSURE SIDE OF THE VALVE.

B2334-1/IL

Figure 3. Available Seal Configurations

Preparing for Installation

CAUTION

To avoid damage to the valve disk during installation, the valve must be in the fully-closed position. If the Type A31A valve is equipped with a fail-open actuator, remove the actuator before installing the valve/actuator assembly or cycle the valve into the fully closed position. Then, take appropriate steps to ensure that the actuator does not cause the valve to open during installation.

1. The Type A31A valve is normally shipped as part of an assembly with an actuator and other accessories such as a valve positioner. If the valve and actuator have been purchased separately or if the actuator has been removed for maintenance, properly mount the actuator and adjust valve/actuator travel and all travel stops before inserting the valve into the line.

Follow the instructions in this manual for adjusting travel stops. Also, refer to a separate actuator instruction manual for detailed actuator mounting and adjustment procedures.

2. If not previously removed, remove the protective end covers from the valve and inspect the valve body to be certain that it is free of foreign material. Also, be certain that adjacent pipelines are free of any foreign material, such as pipe scale or welding slag that could damage the valve seating surfaces.

CAUTION

The Type A31A valve is designed for use with the appropriate piping schedule for the specified ANSI class. Minimum inside diameters for flanges or pipe mating with valves are shown in tables 3 and 4. Be certain to align the valve accurately to avoid contact between the disk and the flanges. Improper alignment or insufficient space for disk rotation could result in damage to the disk.

A31A Valve

3. Select the appropriate gaskets for the application. Flat sheet, spiral wound, or other gasket types, made to ANSI B16.5 group or user's standard, can be used on the valves depending on the service conditions of the application.

4. Refer to table 5 for the quantity and size of flange bolts required.

Installing Wafer-Style Valves



WARNING

The edges of a rotating valve disk have a shearing effect that may result in personal injury. To avoid personal injury, keep clear of the disk edges when rotating the disk.

1. See figure 5 for recommended valve orientation. See table 5 for flange bolt specifications. Install the lower flange bolts first to form a cradle for the valve.
2. Properly orient the valve according to the specific application. For optimum performance, install the valve so that the shaft will be on the high pressure side of the valve at shutoff. Install the valve and the gaskets between the flanges into the cradle formed by the flange bolts.
3. Install the remaining flange bolts, making sure to center the gaskets on the gasket sealing surfaces of the flange and body.
4. Tighten the flange bolts in an alternating criss-cross fashion to a torque value of one-fourth of the final bolting torque. Repeat this procedure several times increasing the torque value each time by a

Table 5. Hex Head Screw, Stud Bolt and Cap Screw Data⁽¹⁾

VALVE SIZE, INCH	NUMBER		SIZE DIA. INCH & THREAD		LENGTH, INCH	
	Class 150	Class 300	Class 150	Class 300	Class 150	Class 300
Single-Flange Style with Stud Bolts						
3	4	8	5/8-11	3/4-10	5-3/4	6
4	8	8	5/8-11	3/4-10	6	6-1/2
6	8	12	3/4-10	3/4-10	6-1/2	7-1/2
8	8	12	3/4-10	7/8-9	7	9
10	12	16	7/8-9	1-8	8	10
12	12	16	7/8-9	1-1/8-8	8-1/2	11
Wafer-Style with Cap Screws						
3	8	16	5/8-11	3/4-10	1-7/8	2
4	16	16	5/8-11	3/4-10	2	2-1/4
6	16	24	3/4-10	3/4-10	2	2-1/2
8	16	24	3/4-10	7/8-9	2-1/4	3
10	24	32	7/8-9	1-8	2-1/2	3
12	24	32	7/8-9	1-1/8-8	2-3/4	3-3/8

1. Thread engagement in accordance with ANSI B31.3 "Chemical Plant and Petroleum Refinery Piping".

fourth of the final desired torque. When the final torque value has been applied, tighten each flange bolt again to allow for gasket compression.

5. For hazardous atmosphere or oxygen service valves, read the following **Warning**, and provide the bonding strap assembly mentioned below if the valve is used in an explosive atmosphere.



WARNING

The valve drive shaft is not necessarily grounded to the pipeline when installed. Personal injury or property damage could result, if the process fluid or the atmosphere around the valve is flammable, from an explosion caused by a discharge of static electricity from the valve components. If the valve is installed in a hazardous area, electrically bond the drive shaft to the valve.

Note

The packing is composed of all conductive packing rings (graphite ribbon packing) to electrically bond the shaft to the valve for hazardous area service or non-conductive PTFE




Figure 4. Optional Shaft-to-Valve Body Bonding Strap Assembly

packing rings. For oxygen service applications, provide alternate shaft-to-valve body bonding according to the following step.

6. Attach the bonding strap assembly (key 131, figure 6) to the shaft with the clamp (key 130, figure 6).
7. Connect the other end of the bonding strap assembly to the valve flange cap screws.

8. For more information, refer to the *Packing Maintenance* section below.

Installing Single-Flange Valves

⚠ WARNING

The edges of a rotating valve disk have a shearing effect that may result in personal injury. To avoid personal injury, keep clear of the disk edges when rotating the disk.

1. See figure 5 for recommended valve orientation. See table 5 for hex head cap screw specifications.
2. Properly orient the valve according to the specific application. For optimum performance, install the valve for reverse flow.
3. Position the valve between the flanges. Be sure to leave enough room for the flange gaskets. Install the lower flange bolts.
4. Select the appropriate gaskets for the application. Flat sheet, spiral wound, or other gasket types, made to the ANSI B16.5 group standard or user's standard, can be used on the valve depending on the service conditions of the application. Install the gaskets and align the valve and the gaskets.
5. Install the remaining bolts.
6. Tighten the flange bolts in an alternating criss-cross fashion to a torque value of one-fourth of the

Table 6. Torque Values for Fasteners

		FASTENER NOMINAL SIZE											
		#10	1/4	5/16	3/8	7/16	1/2	9/16	5/8	3/4	7/8	1	1-1/8
Retaining Ring Screws	Lbf•in												
	Lbf•ft												
	41	100	220	400	53	83	119	166	296	480	720	1000	
	N•m												
Gasket Retaining Bolts	Lbf•in												
	Lbf•ft												
	35	81	167	295	39	59	86	119	210	330	480	617	
	N•m												
		4.0	9.2	19	33	53	80	117	161	286	447	651	837

Note: These values are based upon standard materials, S66286/Inconel screws and ASTM A193GRB6 bolts. For other special fastener materials, please contact your Fisher Controls sales office or sales representative.

final bolting torque. Repeat this procedure several times increasing the torque value each time by a fourth of the final desired torque. When you get to the final torque value, tighten each flange bolt again to allow for gasket compression.

Maintenance

Valve parts are subject to normal wear and must be inspected and replaced as necessary. The frequency of inspection and replacement depends

A31A Valve

upon the severity of service conditions. Because of the care Fisher Controls takes in meeting all manufacturing requirements (heat treating, dimensional tolerances, etc.), use only replacement parts manufactured or furnished by Fisher Controls.



WARNING

Avoid personal injury from sudden release of process pressure. Before performing any maintenance operations:

- **Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open or close the valve.**
- **Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve. Drain the process media from either side of the valve.**
- **Vent the power actuator loading pressure and relieve any actuator spring precompression.**
- **Use lock-out procedures to be sure that the above measures stay in effect while you work on the equipment.**

Replacing Packing

The Type A31A valve is designed so the packing can be replaced without removing the valve from the process pipeline. Packing may be PTFE V-rings or graphite.

If you are installing an ENVIRO-SEAL™ Packing System in an existing valve, follow the instructions in the *ENVIRO-SEAL Packing Instruction Manual* (Form 5320). To remove packing parts in a valve with the ENVIRO-SEAL packing system, follow the procedures for valves using ENVIRO-SEAL packing system in this section.




Figure 5. Properly Installed Wafer Style Valve

For valves with PTFE or graphite packing:

Key numbers for the parts in this section may be found in figure 7.



CAUTION

Tighten the packing flange only enough to prevent shaft leakage. Excessive tightening will only accelerate wear of the packing and could produce higher torques on the valve.

Usually, packing leakage can be eliminated by merely tightening the hex nuts (key 15) located above the packing flange while the valve is in the pipeline. However, if leakage continues, replace the packing.



CAUTION

Never use a wrench or pliers on the valve shaft. A damaged shaft could cut the packing and allow leakage.

1. Before loosening any parts, isolate the valve from the line pressure, release pressure from both sides of the valve body, and drain the process media from both sides of the valve. Then, remove the hex nuts (key 15) and lift off the packing flange (key 11).
2. Remove the hex jam nuts (key 17), anti-blowout flange (key 10) and the packing follower (key 12).

Also remove the anti-blowout ring (key 16) using a needle-nose pliers. The packing (key 13) is now accessible. Refer to figure 6 for details of the blowout protection.

3. Use a packing extractor to remove packing. Insert the corkscrew-like end of the tool into the first piece of packing and pull firmly to remove the packing. Repeat this process until all packing has been removed.

 CAUTION

Be careful when cleaning the packing box. Scratches to the shaft or inside diameter of packing bore might cause leakage.

4. Before installing new packing, clean the packing box.
5. Install new packing (key 13) one ring at a time, using the packing follower (key 12) as a driver. If using split-ring packing, stagger the splits in the rings to avoid creating a leak path.
6. Reinstall all parts. Tighten the packing flange nuts (key 15) as needed to stop leakage under operating conditions.

For valves using the ENVIRO-SEAL packing system:

Normally, the packing nuts should not require re-tightening. However, when servicing an ENVIRO-SEAL packing system, if the springs do not remain nearly flat, retighten the packing box nuts until the springs are almost completely compressed. If leakage continues, replace the packing components as described in the following procedures. Keys numbers in this section may be found in figure 7.

 CAUTION

Be careful when cleaning the packing box. Scratches to the shaft or inside diameter of the packing bore may cause leakage.

1. Before loosening any parts on the valve, isolate the control valve from the line pressure and release pressure from both sides of the valve body.
2. Loosen the two packing hex nuts evenly to remove spring tension, then remove the nuts.

3. Remove the packing flange and spring stack. The spring stack is held in place by an O-ring on the packing flange. Remove the two hex jam nuts and remove the anti-blowout flange, packing flange, anti-blowout ring, packing box ring, anti-extrusion washer, packing set, and packing box ring.

 CAUTION

The valve shaft surface condition is critical in making and maintaining a good seal. If the valve shaft surface is scratched, nicked, dented, or worn, replace the valve shaft before replacing the packing system components.

4. Inspect the existing valve shaft. If necessary, replace the valve shaft as described in the procedures in this section.
5. Install the new packing system components as described in the *ENVIRO-SEAL Packing Instruction Manual* (Form 5320).

Removing the Valve from the Pipeline

1. Disconnect any operating lines providing air pressure, electric power, or a control signal to the actuator. Be sure the actuator cannot suddenly open the valve. Vent the power actuator loading pressure.
2. Use bypass valves or completely shut off the process to isolate the valve from process pressure. Relieve process pressure on both sides of the valve. Drain the process media from either side of the valve.

 CAUTION

Damage to the valve disk, piping or pipe flanges can occur if the disk is not closed when the valve is being removed from the pipeline. If necessary, stroke the actuator to place the disk in the closed position while removing the valve from the pipeline.

3. Loosen the flange bolting that holds the valve. Make sure the valve cannot slip or twist while loosening and removing the bolting.
4. Make certain the valve disk is closed and remove the valve from the pipeline. Support the valve properly and move the valve to an appropriate work area.

A31A Valve

Removing/Installing the Seal Ring

Unless otherwise indicated, key numbers and part names are listed in figure 8.

Note

For larger valves, it is possible to replace the seal ring (key 5) while the actuator is mounted to the valve and can be accomplished by cycling the valve to 90 degrees open.

1. After removing the valve from the pipeline, remove the manual or power actuator. Manually rotate the drive shaft (key 3) counterclockwise until the disk has moved a full 180 degrees away from the closed position.
2. Lay the valve flat on a work bench in a secure position with the retaining ring (key 18) and retaining ring screws (key 19) facing up. Properly secure the valve on a suitable worktable so it can not slip, twist, or fall during maintenance. Remove all retaining ring screws.
3. Remove the retaining ring by placing a socket head retaining ring screw from the retaining ring in each of the two retaining ring jacking screw holes. Slowly turn the screws until the retaining ring has been lifted from the valve body. Remove the retaining ring to expose the seal ring in the T-slot area of the valve body.

Note

The Type A31A valve is available with different seal designs and components. See figure 3 to identify the specific seal design.

4. Insert a regular screw driver or other similar tool under the top edge of the seal ring (key 5), and gently pry it out of the T-slot area in the valve body. Take care not to damage the seal ring or T-slot area of the valve body. After the seal ring has been removed, clean the T-slot area, retaining ring, and, if required, polish the disk thoroughly with fine steel wool or other appropriate material.

PTFE Seal Installation

Unless otherwise indicated, key numbers and part names are listed in figure 8.

A maintenance kit with installation tools is available through your Fisher Controls representative or sales office.

1. Locate the replacement seal ring (key 5) and note the shape of the ring. The ring is wider across one edge diameter and narrower across the other edge diameter. Also, note the wide groove around the outside circumference.

Before installing the seal ring into the valve body, place the backup ring (key 6) into the wide, outer groove of the seal ring.

2. Install the seal ring and backup ring assembly in the valve body. The wider outside diameter of the seal ring, goes into the T-slot area of the valve body as shown in figure 6. Start the edge with the wider diameter into the T-slot of the valve body using a blunt-end screwdriver. If a maintenance kit is available, use the seal ring installation tools.
3. Carefully tuck the backup ring downward into the valve body T-slot until the seal ring and backup ring are completely entrapped in the valve body T-slot.
4. Completely seat the seal ring in the valve body T-slot. Re-install the retaining ring (key 18) and retaining ring screws (key 19). Tighten the screws just enough to eliminate any movement of the retaining ring. Using a blunt-end tool, carefully tuck the lip of the seal ring under the retaining ring.
5. When the seal ring is under the lip of the retaining ring, tighten the screws according to standard procedures. Do not fully torque screws at this time. Final tightening of the screws is accomplished in step 7.
6. Manually rotate the drive shaft (key 3) clockwise 180 degrees to return the disk (key 2) to its closed position.
7. The final seating of the retaining ring cap screws can now be done. For the screw torque values, refer to table 6. The seal is now completely installed and the valve may be placed in service.


Novex Seal and Phoenix III Fire-Tested Seal Installation

Unless otherwise indicated, key numbers and part names are listed in figure 8.

A maintenance kit with installation tools is available through your Fisher Controls representative or sales office.

1. Locate the replacement seal ring (key 5) and note the shape of the ring. The ring is wider across one edge diameter and narrower across the other edge diameter. Also, note the wide groove around the outside circumference.

Before installing the seal ring into the valve body, place the backup ring (key 6) into the wide, outer groove of the seal ring.



A5251-17/IL

Figure 6. Typical Seal Installation

2. Install the seal ring and backup ring assembly in the valve body. The wider outside diameter of the seal ring goes into the T-slot area of the valve body as shown in figure 6. Start the edge with the wider diameter into the T-slot of the valve body using a blunt-end screwdriver. If a maintenance kit is available, use the seal ring installation tools. Do not use the screwdriver or seal ring tool directly on the metal seat. Use the tool only on the backup ring.
3. Carefully tuck the backup ring downward into the valve body T-slot until the seal ring and backup ring are completely entrapped in the valve body T-slot.

Note

On larger valves, it may be more efficient to have someone hold down the seal ring while you push the backup ring into the T-slot.

4. Once the seal ring and backup ring have been fully installed into the valve body T-slot, the retaining ring gasket can be installed. This gasket is a thin graphite material. Use extreme care to avoid damaging the gasket while punching one initial screw hole through the gasket for alignment.
5. Install the retaining ring, and align the screw holes in the retaining ring with the holes in the valve body. Install the first retaining ring screw through the punched hole in the retaining ring gasket. Install the other retaining ring screws by pushing them through

the graphite gasket and threading them into the valve body.

6. Tighten the retaining ring screws just enough to eliminate any movement of the retaining ring. Do not over-tighten the retaining ring screws.

WARNING

Avoid personal injury or property damage caused by the impact of a falling or tipping valve. Support large valves during maintenance.

7. To complete this step, stand the valve up. Support the valve securely using methods appropriate for the valve size. If a vise or other clamps are being used, make certain the flange gasket sealing area of the valve body is not damaged.
8. Manually rotate the drive shaft (key 3) to turn the disk clockwise to meet the seal ring.
9. Place a piece of rubber, or other soft material, between the disk and internal travel stop to protect the disk. With a rubber mallet, tap the disk until it contacts the internal travel stop. When the disk makes contact with the stop, manually rotate the disk counterclockwise back out of the seal ring to a 90-degree open position.
10. The final seating of the retaining ring screws can now be done. For the screw torque values, refer to table 6.
11. Repeat steps 8 and 9 two more times.

Note

When attaching the actuator to the valve, make sure the valve disk is not in contact with the internal travel stop. The valve disk should be positioned from 0.001 to 0.030 inch (0.03 to 0.76 mm) away from the internal stop in the valve body.

12. Use an appropriate tool (such as a feeler gauge) and position the disk from 0.001 to 0.030 inch (0.03 to 0.76 mm) away from the internal stop in the valve body.

This adjustment is necessary to be certain that the actuator output torque is fully absorbed by the actuator travel stop or by the actuator. The internal travel stop in the valve body should not absorb any of the actuator torque.

A31A Valve

Cryogenic Seal Installation

Unless otherwise indicated, key numbers and part names are listed in figure 8.

A maintenance kit with installation tools is available through your Fisher Controls representative or sales office.

1. Locate the replacement seal ring (key 5) and note the shape of the ring. The ring is wider across one edge diameter and narrower across the other edge diameter. Also, note the wide groove around the outside circumference. If an aluminum backup ring is provided, fit this over the back of the seal ring (matching seal and backup ring angles) prior to installation in the valve.
2. Install the seal ring (key 5) in the valve body by first placing the wider outside diameter of the seal ring into the T-slot area of the valve body as shown in figure 6.
3. Once the seal ring has been fully installed into the body T-slot, the retaining ring gasket can be installed. This gasket is a thin graphite material. Use extreme care to avoid damaging the gasket while punching one initial screw hole through the gasket for alignment.
4. Install the retaining ring, and align the screw holes in the retaining ring with the holes in the valve body. Install the first retaining ring screw through the punched hole in the retaining ring gasket. Install the other retaining ring screws by pushing them through the graphite gasket and threading them into the valve body.
5. Tighten the retaining ring screws just enough to eliminate any movement of the retaining ring. Do not over-tighten the retaining ring screws.




WARNING

Avoid personal injury or property damage caused by the impact of a

falling or tipping valve. Support large valves during maintenance.

6. To complete this step, stand the valve up. Support the valve securely using methods appropriate for the valve size. If a vise or other clamps are being used, make certain the flange gasket sealing area of the valve body is not damaged.
 7. Manually rotate the drive shaft (key 3) to turn the disk clockwise to meet the seal ring.
 8. Place a piece of rubber, or other soft material, between the disk and internal travel stop to protect the disk. With a rubber mallet, tap the disk until it contacts the internal travel stop. When the disk makes contact with the stop, manually rotate the disk counterclockwise back out of the seal ring to a 90-degree open position.
 9. The final seating of the retaining ring screws can now be done. For the screw torque values, refer to table 6.
 10. Repeat steps 7 and 8 two more times.
- Note**
- When attaching the actuator to the valve, make sure the valve disk is not in contact with the internal travel stop. The valve disk should be positioned from 0.001 to 0.030 inch (0.03 to 0.76 mm) away from the internal stop in the valve body.**
11. Use an appropriate tool (such as a feeler gauge) and position the disk from 0.001 to 0.030 inch (0.03 to 0.76 mm) away from the internal stop in the valve body.

This adjustment is necessary to be **certain** that the actuator output **torque is fully absorbed** by the **actuator travel stop or by the actuator**. The internal travel stop in the valve body should not absorb any of the actuator torque.



C0766 / IL

Figure 7. Anti-Blowout Protection Detail

Anti-Blowout Protection, Packing, Valve Shaft(s), Disk, and Bearing Maintenance

Note

The 10- through 12-inch class 150 valves and 8- through 12-inch class 300 valves have a two-piece shaft. The shaft with the keyed end is called the drive shaft. The shaft opposite the drive shaft is called the follower shaft.

The 3- through 8-inch class 150 valves and 3 through 6-inch class 300 valves have a one-piece shaft. This one-piece shaft is keyed and is called the drive shaft.

the valve shaft could damage the valve internal parts.

If necessary, use a wheel puller to remove the lever or actuator from the valve shaft. It is okay to tap the wheel puller screw lightly to loosen the lever or actuator, but hitting the screw with excessive force could also damage internal valve parts.

Never use a wrench or pliers on the drive shaft. A damaged shaft could cut the packing and allow leakage.

Unless otherwise indicated, key numbers and part names are listed in figure 9.

1. Remove the actuator and valve, as an assembly, from the pipeline, and then remove the actuator from the valve.

Removal

WARNING

The edges of a rotating valve disk (key 2) have a shearing effect that might result in personal injury. To avoid personal injury, keep clear of the disk edges when rotating the disk.

CAUTION

When removing the actuator from the valve, do not use a hammer or similar tool to drive the lever off the valve shaft. Driving the lever or actuator off

Note

It is not necessary to remove the retaining ring and seal ring when removing the shaft(s) and disk.

2. Secure the valve in an upright position. Rotate the disk (key 2) 180 degrees counterclockwise from the fully closed position by manually turning the drive shaft.
3. Removing the Anti-Blowout Protection (refer to figure 7):

a. **For PTFE or Graphite Packing:** Remove the hex nuts and pull off the packing flange. Remove the hex jam nuts and the anti-blowout flange. Remove the packing follower.

b. **For ENVIRO-SEAL Packing System:** Evenly loosen and remove the two packing hex nuts, the

A31A Valve

packing flange, the spring stack, the two hex jam nuts, the anti-blowout flange, and the packing follower.

4. Remove the anti-blowout ring from around the drive shaft using a needle nose pliers.

Note

3- through 12-inch valve sizes (classes 150 and 300) have a bearing stop (key 8, figure 8) pressed into the bearing bore immediately after the packing box.

Do not attempt to remove the bearing stop which is found in the drive shaft bearing bore immediately after the packing box. The bearing stop is pressed into the bearing bore. If the bearing stop needs replacement, contact your Fisher Controls sales office or sales representative for more information.

5. Remove the packing from around the drive shaft.

Note

Different valves require slightly different procedures because different valve sizes/ pressure classes have different methods of connecting the disk and shaft(s). To identify the proper procedures, refer to the list below.

- **Class 150, 3- through 8-inch sizes: One-piece shaft with 1 taper key.**
- **Class 150, 10- and 12-inch sizes: Two-piece shaft. 1 taper key in the drive shaft; 1 disk pin in the follower shaft.**
- **Class 300, 3- through 6-inch sizes: One-piece shaft with 1 taper key.**
- **Class 300, 8- and 10-inch sizes: Two-piece shaft. 1 taper key in the drive shaft; 1 disk pin in the follower shaft.**
- **Class 300, 12-inch size: Two-piece shaft with 2 tangential pins in the drive shaft; 1 disk pin in the follower shaft.**

6. Proceed as appropriate, using the following instructions.

For valves with taper key(s), locate the taper key(s) (key 9, figure 8) which runs through the drive shaft boss on the back of the valve disk. Using a pin punch on the smaller end of the key, drive it out of the disk and shaft. Driving a taper key in the wrong direction will tighten it.

Note

Certain valve sizes may have a taper key that is arc spot welded in place. To remove the key, use a punch on the smaller end of the taper key and drive it out of the disk and shaft, breaking the weld.

For valves with tangential pins and/or disk pins, locate the tangential pins (key 26) in the drive shaft (key 3) and the disk pin (key 26) in the follower shaft (key 4).

- a. If a maintenance kit is available, use the pin extractor to remove the disk pins. Select the correct size pin extractor tip with screws of proper thread size to match the thread size in the disk pins. If a maintenance kit is not available, see steps c and d below.
- b. Screw the pin extractor tip into the pin as far as possible. With an upward, straight sliding motion, pull out the pin. Repeat the same procedure for the other pins.
- c. Use a threaded rod with an appropriate spacer and nut as an extractor tool. If using a threaded rod, choose a rod with threads that fit the inside thread of the pins. The rod should extend several inches above the disk when it is screwed into a pin.
- d. After screwing the rod into the pin, slide the spacer over the rod and pin. Thread the nut onto the rod and tighten it. As the nut is tightened, the nut will drive the spacer against the disk. The increasing force will draw the pin from the disk.

7. Valves with a two-piece shaft have a gasket retainer and gasket (keys 20 and 21) on the follower shaft side of the valve. Remove the hex head bolts and lockwashers (keys 23 and 22) from the gasket retainer and remove the gasket retainer and gasket to expose the end of the follower shaft.

8. Support the valve disk properly, and remove the follower shaft. Pull the follower shaft from the valve body. Use a shaft extractor screwed into the puller hole in the end of the follower shaft.

9. Support the valve disk properly, and remove the drive shaft. Pull out the drive shaft (key 3) by hand-pulling or by using a shaft extractor screwed into the end of the shaft.

 **CAUTION**

To avoid damage to the disk, seal ring, and T-slot area, do not force the disk past the seal or T-slot area. Remove the disk from the opposite side of the valve body.

10. After removing the shaft(s), remove the disk and the thrust bearings. Do not force the disk past the seal ring or T-slot area.

11. Remove the journal bearings (key 7). Using a suitable punch or puller, drive or pull the journal bearing(s) into the valve body bore from the drive shaft bearing bore. Do not attempt to remove the bearing stop (key 8). Remove the journal bearing from the follower shaft bearing bore.

12. Inspect the valve body bore, bearings, bearing bores, and packing box for damage.

Installing a One-Piece Shaft

Unless otherwise indicated, key numbers and part names are listed in figure 8.

1. Secure the valve in an upright position. Allow for easy access to the valve body bore. Allow for easy access to the drive shaft bearing bore.
2. Inspect all parts removed from the valve for wear or damage. Replace any worn or damaged parts. Clean the valve body and all parts to be installed with an appropriate solvent or degreaser.

 **CAUTION**

Premature valve failure and loss of process control may result if bearings are improperly installed or are damaged during installation.

3. Using caution to prevent damage to the bearing, insert one journal bearing (key 7) from the valve body bore into the drive shaft bearing bore until it hits the bearing stop (key 8). When properly installed, a portion of the journal bearing will extend into the valve body bore.

4. Insert one journal bearing from the valve body bore into the shaft bearing bore opposite the journal bearing installed in step 3. When correctly installed, this journal bearing will be flush with the valve body bore.

5. Install the valve disk by placing the disk into the valve body bore so the curved side of the disk passes through the end of the valve body that does not contain the T-slot. Align the shaft bore in the disk with the bearing bores.

6. Insert the drive shaft end opposite the keyed end into the valve body through the packing box. Push the shaft through the bearing stop. Taking care not to dislodge the journal bearing, push the shaft through the journal bearing and the valve disk and into the bore on the opposite side of the valve body.

 **CAUTION**

To avoid damage to the taper key, tangential pins, disk pins, valve disk, or shaft(s) resulting from the application of excessive force, use appropriate care when driving the key or pins into the disk hub and shaft(s). Use the right tool. Do not use excessive force.

7. Be sure the taper key disk shaft joint is free of oil or grease. If necessary, remove any excess welding material from the taper key.

8. Align the taper key hole in the shaft with the holes in the shaft boss on the disk. Insert the taper key. Use a flat-end punch to drive the taper key until solid contact is felt. Measure the depth of the taper key head for a reference during the following steps.

- a. Drive the taper key in farther as follows:

Valve Size, Inches	Minimum Depth to Drive Taper key After Initial Solid Contact, Inches (mm)
ANSI Class 150 and 300, size 3, 4, 6-inch valves, & 8-inch ANSI Class 150 valves	0.188 (5 mm)

b. The disk shaft, and taper key assembly must be inspected to verify that the taper key spans the entire shaft flat width. If so, this procedure is complete. If not, the taper key must be driven in farther until this condition is satisfied. However, do not exceed the following depth limits:

A31A Valve

Valve Size, Inches	Minimum Allowable Depth to Drive Taper key After Initial Solid Contact, Inches (mm)
3, and 4-inch ANSI Class 150/300	0.281 (7 mm)
6-inch ANSI Class 300, and 8-inch ANSI Class 150	0.312 (8 mm)

9. After driving the taper key in place, arc spot weld the head of the taper key to the disk as shown in figure 8. For valve sizes 3-, 4-, and 6-inch, use an arc spot weld bead of 1/8-inch diameter. For valve sizes 8-, 10-, and 12-inch sizes, use an arc spot weld bead of 3/16-inch diameter.

10. Install the packing as described in the *Packing Replacement* section or in the *ENVIRO-SEAL Packing Instruction Manual* (Form 5320).

Installing a Two-Piece Shaft

Unless otherwise indicated, key numbers and part names are listed in figure 9.

1. Secure the valve in an upright position. Allow for easy access to the valve body bore. Allow for easy access to the drive shaft bearing bore and the follower shaft bearing bore.
2. Inspect all parts removed from the valve for wear or damage. Replace any worn or damaged parts. Clean the valve body and all parts to be installed with an appropriate solvent or degreaser.



CAUTION

Premature valve failure and loss of process control may result if bearings are improperly installed or are damaged during installation.

3. Using caution to prevent damage to the bearings, insert the required number of journal bearings (key 7) from the valve body bore into the drive shaft bearing bore. When properly installed, one end of the journal bearing(s) will be flush with the interior end of the packing box, the other end of the journal bearing(s) will be flush with the valve body bore.

The drive shaft thrust bearing (key 24) will be installed in step 5.

4. Insert one journal bearing from the valve body bore into the follower shaft bearing bore so it is flush with the valve body bore.
5. Insert the drive shaft into the valve body through the packing box. Push the drive shaft through the

journal bearing. Hold the drive shaft thrust bearing (key 24) in the valve body bore against the opening of the drive shaft bearing bore. Push the drive shaft through the bearing bore just enough to hold the thrust bearing.

6. Insert the follower shaft through the bore in the valve body uncovered by removal of the gasket retainer. Hold the follower shaft thrust bearing (key 24) in the valve body bore against the opening of the follower shaft bearing bore. Push the follower shaft through the bearing bore just enough to hold the thrust bearing.

7. Install the valve disk. Place the flat side of the disk on a flat surface. Then, move the valve body from its upright position and suspend the valve body over the disk so the seal ring/T-slot area is facing up. Align the shaft bores through the disk with the drive shaft and follower shaft bores. Lower the valve body over the disk using caution not to dislodge or damage the thrust bearings placed on the ends of the shafts.

8. With the valve disk properly positioned in the valve body, push the drive shaft and follower shaft the rest of the way through the thrust bearings and into the shaft bores in the valve disk.
9. Align the holes in the shafts with the holes in the disk.



CAUTION

To avoid damage to the taper key, tangential pins, disk pins, valve disk, or shaft(s) resulting from the application of excessive force, use appropriate care when driving the key or pins into the disk hub and shaft(s). Use the correct tool, and do not use excessive force.

10. Before installing the taper key, be sure the taper key disk shaft joint is free of oil or grease. If necessary, remove any excess welding material from the taper key.

11. Install the appropriate taper key, tangential pins, and disk pins (see table 11).

12. Install the taper key by aligning the taper key hole in the shaft with the holes in the shaft boss on the disk. Insert the taper key. Use a pin punch to drive the taper key until solid contact is felt. Measure the depth of the taper key head for a reference during the following steps.

- a. Drive the taper key in farther as follows:

Valve Size, Inches	Minimum Depth to Drive Taper key After Initial Solid Contact, Inches (mm)
8-inch ANSI Class 300, 10- and 12-inch ANSI Class 150, & 10-inch ANSI Class 300 valves	0.219 (6 mm)

b. The disk shaft, and taper key assembly must be inspected to verify that the taper key spans the entire shaft flat width. If so, this procedure is complete. If not, the taper key must be driven in farther until this condition is satisfied. However, do not exceed the following depth limits:

Valve Size, Inches	Minimum Allowable Depth to Drive Taper key After Initial Solid Contact, Inches (mm)
8-inch ANSI Class 300, and 10- and 12-inch ANSI Class 150	0.375 (10 mm)
10-inch ANSI Class 300	0.406 (11 mm)

13. After driving the taper key in place, arc spot weld the head of the taper key to the disk as shown in figure 8. For valve sizes 10- and 12-inch, use an arc spot weld bead of 3/16-inch in diameter. packing box. Install the packing around the drive shaft.

14. Install the packing as described in the *Packing Replacement* section or in the *ENVIRO-SEAL Packing Instruction Manual* (Form 5320).

Installing the Gasket Retainer

Valves with a two-piece shaft use a gasket retainer and gasket to cover the follower shaft opening in the valve body.

1. Replace the gasket (key 21) and gasket retainer (key 20) over the end of the follower shaft. Use a new gasket.
2. Replace the four hex head bolts (key 23) and lockwashers (key 22) to hold the gasket retainer in place.
3. Be sure to center the gasket over the follower shaft bore before retightening the bolts. Tighten

down the bolts evenly in a crossover or star pattern. Refer to table 6 for proper torque values.

Parts Ordering

When replacement parts are required, always use genuine Fisher Controls parts.

When corresponding with your Fisher Controls representative or sales office about the Type A31A valve, always provide the valve serial number. For valve/actuator combinations assembled at the factory, the valve serial number is stamped on the nameplate attached to the actuator.

Parts Reference

Key	Description
1	VALVE BODY
2	DISK
3	DRIVE SHAFT
4	FOLLOWER SHAFT
5	SEAL RING
6	BACKUP RING
7	JOURNAL BEARING
8	BEARING STOP
10	ANTI-BLOWOUT FLANGE
11	PACKING FLANGE
12	PACKING FOLLOWER
13	PACKING
14	STUD
15	HEX NUT
16	ANTI-BLOWOUT RING
17	HEX JAM NUT
18	RETAINING RING
19	RETAINING RING SCREW
20	GASKET RETAINER
21	GASKET
22	LOCKWASHER,
23	HEX HEAD BOLT
24	THRUST BEARING
25	KEY (FOR DRIVE SHAFT)
26	TANGENTIAL PIN OR DISK PIN
27	RETAINING RING GASKET, GRAPHITE
29	NAMEPLATE (NOT SHOWN)
30	DRIVE SCREW (NOT SHOWN)
33	FLOW DIRECTION ARROW (NOT SHOWN)




Figure 8. Fisher A31A NPS 3 through 12 Typical Assembly

Fisher, POSI-SEAL, and ENVIRO-SEAL are marks owned by one of the companies in the Emerson Process Management business division of Emerson Electric Co. Emerson Process Management, Emerson, and the Emerson logo are trademarks and service marks of Emerson Electric Co. All other marks are the property of their respective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice. Neither Emerson, Emerson Process Management, nor any of their affiliated entities assumes responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

Emerson Process Management
 Marshalltown, Iowa 50158 USA
 Sorocaba, 18087 Brazil
 Chatham, Kent ME4 4QZ UK
 Dubai, United Arab Emirates
 Singapore 128461 Singapore
 www.Fisher.com

