



L2t Installation  
Documents &  
Field Support

[emrson.co/FieldSupportL2t](http://emrson.co/FieldSupportL2t)

Do not install, operate, or maintain an L2t liquid level controller without being fully trained and qualified in valve, actuator, and accessory installation, operation, and maintenance. To avoid personal injury or property damage, it is important to carefully read, understand, and follow all contents of this product's instruction manual (D104782X012) and related product documentation, including all the safety cautions and warnings contained therein. These documents may be accessed by scanning the QR Code. If a hard copy of the instruction manual is needed contact your Emerson sales office.

Neither Emerson, nor any of its affiliated entities assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use, and maintenance of any product remains solely with the purchaser and end user.

